


# **M2(W) / M3(W)**

## **Spare Parts List**

**M2(W) from machine no. 101**  
**M3 from machine no. 194**  
**M3W from machine no. 284**

# M2(W) Spare parts list



# M2(W)


## Spare parts list

Pos. No.	Order no.	Notes	Pos. No.	Order no.	Notes
1	6220-01	M2			
1	6220-20	M2W			
2	6340-01				
3	6341-05				
4	6341-06				
5	9962-04	M8x20			
6	9930-32	D8/17			
7	9969-31	M8			
8	4970-81				
9	9961-14	M6x25			
10	9990-43				
11	6320-03				
12	9938-74				
13	6371-15	Left			
14	6371-16	Right			
15	6371-10				
16	6371-01	Left			
17	6371-02	Right			
18	9969-16	M6			
19	9930-02	D6/12			
20	9961-20	M6x12			
21	9990-08				
22	6350-12				
23	9969-32	M8			
24	9930-51	D8/17			
25	6372-01				
26	6372-15				
27	6372-10	Left			
28	6372-11	Right			
29	9961-21	M6x16			
30	4612-01				
31	9985-40	810 mm			

# M2W

## Spare parts list

---




# M2W

## Spare parts list

Pos. No.	Order no.	Notes	Pos. No.	Order no.	Notes
1	6222-30				
2	6220-25				
3	6220-26				
4	9930-20	D17/30			
5	9964-71	M16x30			
6	9936-27				
7	6320-29				
8	9942-33				
9	9968-97	M20			
10	4522-42				
11	4522-40				
12	9913-41	M16x90 KV12.9			
13	9930-35	D12/24			
14	9965-07	M12x70			
15	9969-46	M10			
16	9963-18	M10x75			
17	9964-79	M16x120			
18	6220-34				
19	6220-35				
20	6220-38	0.5 mm			
21	6220-37	1 mm			
22	6220-33				
23	9937-45	I72			
24	9950-05	6305-2RS			
25	6220-30				
26	6220-36				
27	9969-84	M16			
28	6220-27				

# M3(W) Spare parts list



# M3(W)


## Spare parts list

Pos. No.	Order no.	Notes	Pos. No.	Order no.	Notes
1	6320-01	M3	46	6310-13	Left
1	6320-20	M3W	47	6310-14	Right
2	6340-01				
3	6341-05				
4	6341-06				
5	9962-04	M8x20			
6	9930-32	D8/17			
7	9969-31	M8			
8	4970-81				
9	9961-14	M6x25			
10	9990-43				
11	6320-03				
12	9938-74				
13	6930-22				
14	6371-15	Left			
15	6371-16	Right			
16	6371-10				
17	6371-01	Left			
18	6371-02	Right			
19	9969-16	M5			
20	9930-02	D6/12			
21	9961-20	M6x12			
22	9990-08				
23	6350-12				
24	9969-32	M8			
25	9930-51	D8/17			
26	6372-01				
27	6372-15				
28	6372-10	Left			
29	6372-11	Right			
30	9961-21	M6x16			
31	4612-01				
32	9985-40	810 mm			
33	6930-25	Left			
34	6930-26	Right			
35	6930-29	Left			
36	6930-30	Right			
37	6930-35				
38	6930-34				
39	9943-05				
40	9968-79	M5			
41	9929-19	M5x25			
42	9929-15	M5x16			
43	9943-26	Red			
44	9943-27	White			
45	9961-20	M6x12			

# M3W

## Spare parts list

---






# M3W

## Spare parts list

Pos. No.	Order no.	Notes	Pos. No.	Order no.	Notes
1	6322-30				
2	6320-25				
3	6320-26				
4	9930-20	D17/30			
5	9964-71	M16x30			
6	9936-27				
7	6320-29				
8	9942-33				
9	9968-97	M20			
10	6322-43				
11	9913-41	M16x90 KV12.9			
12	9964-77	M16x65			
13	6322-45				
14	9961-20	M6x12			
15	6322-46	Left			
15	6322-47	Right			
16	9969-46	M10			
17	9963-18	M10x75			
18	9964-98	M20x30			
19	9930-15	D22/59			
20	6320-34	0.5 mm			
21	6320-35	1 mm			
22	6320-33				
23	9937-48	I80			
24	9950-07	6307-2RS			
25	6320-30				
26	6320-32				

# M2(W) / M3(W) Spare parts list




# M2(W) / M3(W)

## Spare parts list

Pos. No.	Order no.	Notes	Pos. No.	Order no.	Notes
1	6311-16	1400x2900	40	6313-10	
1	6211-21	1400x2900	41	6313-11	
2	6211-01	1250x2400	42	9962-19	M8x12
3	6311-30		43	9961-21	M6x16
4	9993-12	Red	44	9990-38	
5	6311-31		45	6313-02	
6	9993-13	White	46	4016-05	
7	6311-32		47	6310-03	
8	6211-17		48	6210-13	M2(W)
9	4510-09				
10	9969-16	M6			
11	9930-02	D6/12			
12	9934-13	Ø1,5x11x32			
13	9961-12	M6x20			
14	9962-04	M8x20			
15	2810-18	D8/25			
16	9930-32	D8/17			
17	9969-32	M8			
18	9963-12	M10x30			
19	9930-25	D10/30			
20	9968-44	D10/21			
21	9969-45	M10			
22	9962-05	M8x25			
23	9963-01	M10x25			
24	6310-05				
25	4512-12				
26	4512-11				
27	4512-13	Left			
28	4512-14	Right			
29	4412-21	Small			
30	4611-00				
31	4412-20	Big			
32	4512-08	Small, left			
33	4512-09	Small, right			
34	4512-05	Big, left			
35	4512-06	Big, right			
36	4012-11				
37	9937-31	U44			
38	9933-25	Ø2x10			
39	6313-12				

# M2(W) / M3 Spare parts list



# M2(W) / M3


## Spare parts list



Pos. No.	Order no.	Notes	Pos. No.	Order no.	Notes
1	4750-02	540/750 rpm	47	3263-00	
2	4160-01	L-side/R-thread	48	3260-07	
3	4160-02	R-side/L-thread	49	9965-02	M12x65
4	4056-10		50	9934-03	
5	4056-03		51	9969-60	M12
6	4058-05	Right	52	4652-11	
7	4058-06	Left	53	9934-02	
8	4161-02	Left	54	4653-02	
9	4161-01	Right	55	9990-99	14x20x10
10	4158-05		56	9936-29	14x22x4
11	9913-20	M8x10	57	9934-31	
12	4560-01	Ø20xØ30x5	61	9930-07	D6/17
13	9929-35	M8x20	62	9961-04	M6x16
14	9930-32	D8/17	63	9962-03	M8x16
15	9969-31	M8	64	9965-01	M12x35
16	4550-05	Left	65	9930-35	D12/24
17	4550-06	Right	66	9969-62	M12
18	9933-02	Ø8x40	67	4650-12	E1 T 2 Left/ 2 Right
19	9933-11	Ø5x40	67	4650-20	E2 T 2 Left/ 2 Right
20	4051-05		67	4650-28	E6 T 2 Left/ 2 Right
21	9936-37	35x62x12	68	9936-28	
22	9950-02	6305-2RS	69	9937-13	U 14
23	4155-04	Right thread	70	9913-19	M8x10
24	9933-12	Ø8x45	71	6350-11	
25	9933-17	Ø5x45	72	9961-12	M6x20
26	3265-02	15 teeth	73	9930-02	D6/12
27	3262-05		74	9969-16	M6
28	3260-04		75	4655-05	
29	9963-07	M10x25	76	4653-15	
30	3260-05		77	4690-05	
31	4062-05	Left thread	78	9934-07	
32	4454-05		79	9990-26	
33	9937-40	I60	80	6350-08	
34	4557-02		81	9930-51	D8/16
35	4156-02		82	9962-04	M8x20
37	9931-56	8x7x25	83	9969-32	M8
38	4652-03		84	9985-84	
39	4652-08		85	6330-01	
40	4652-11	17/24 teeth	86	4470-01	
41	4660-00		87	9965-03	M12x30
42	4652-09				
43	9950-03	6206-2RS			
44	4652-01				
45	3260-09				
46	9990-90				

# M3W



## Spare parts list



## Spare parts list

Pos. No.	Order no.	Notes	Pos. No.	Order no.	Notes
1	4750-02	540/750 rpm	48	3260-07	
2	4160-01	L-side/R-thread	49	9965-02	M12x65
3	4160-02	R-side/L-thread	50	9934-03	
4	4056-10		51	9969-60	M12
5	4056-03		52	4652-11	
6	4058-05	Right	53	9934-02	
7	4058-06	Left	54	4653-02	
8	4161-02	Left	55	9990-99	14x20x10
9	4161-01	Right	56	9936-29	14x22x4
10	4158-05		57	9934-31	
11	9913-20	M8x10	61	9930-07	D6/17
12	4560-01	Ø20xØ30x5	62	9961-04	M6x16
13	9929-35	M8x20	63	9962-03	M8x16
14	9930-32	D8/17	64	9965-01	M12x35
15	9969-31	M8	65	9930-35	D12/24
16	4550-05	Left	66	9969-62	M12
17	4550-06	Right	67	4650-12	E1 T 2 Left/ 2 Right
18	9933-02	Ø8x40	67	4650-20	E2 T 2 Left/ 2 Right
19	9933-11	Ø5x40	67	4650-28	E6 T 2 Left/ 2 Right
20	4051-05		68	9936-28	
21	9936-37	35x62x12	69	9937-13	U 14
22	9950-02	6305-2RS	70	9913-19	M8x10
23	4155-04	Right thread	71	6350-11	
24	9933-12	Ø8x45	72	9961-12	M6x20
25	9933-17	Ø5x45	73	9930-02	D6/12
26	3265-02	15 teeth	74	9969-16	M6
27	3262-05		75	4655-05	
28	3260-04		76	4653-15	
29	9963-07	M10x25	77	4790-47	
30	3260-05		78	9942-11	
31	4062-05	Left thread	79	9990-26	
32	4454-05		80	6350-08	
33	9937-40	I60	81	9930-51	D8/16
34	4557-02		82	9962-04	M8x20
35	4156-02		83	9969-32	M8
37	9931-56	8x7x25	84	9985-84	
38	4652-03		85	6330-01	
39	4652-08		86	4470-01	
40	4652-11	17/24 teeth	87	9965-03	M12x30
41	4660-00		88	4790-36	
42	4652-09		89	4790-43	
43	9950-03	6206-2RS	90	6390-35	
44	4652-01		91	9969-60	
45	3260-09		92	4790-38	
46	9990-90		93	9941-04	
47	3263-00		94	9941-34	

# M2(W) / M3(W) Spare parts list





# M2(W) / M3(W)

## Spare parts list

Pos. No.	Order no.	Notes	Pos. No.	Order no.	Notes
1	6381-03		46	9936-80	
2	6381-04		47	9983-09	
3	6381-13		48	9990-19	
4	9989-85				
5	9961-21	M6x16			
6	9930-02	D6/12			
7	9969-16	M6			
8	6381-18				
9	6381-16				
10	6381-17				
11	9930-53	D8/15/3			
12	9962-03	M8x16			
13	2810-18	D8/25			
14	6381-09				
15	9993-11				
16	9969-31	M8			
17	9930-32	D8/17			
18	6384-19	M2W / M3W			
18	6381-19	M2 / M3			
19	9962-04	M8x20			
20	4581-29				
21	4581-28				
22	9934-32				
23	4581-25				
24	9969-60	M12			
25	9930-35	D12/24			
26	9961-23	M6x30			
27	6381-19	M3			
28	9969-16	M6			
29	9990-43				
30	6384-29				
31	4584-26				
32	6384-28				
33	4584-25				
34	4920-50				
35	4581-29				
36	9990-60	D24			
37	9987-04				
38	9990-61	D40			
39	4581-15				
40	9934-14				
41	4581-37				
42	9983-29				
43	9936-79				
44	9982-06				
45	9990-84				





